

# REPLACING THE COVERMATE FOAM GRIP



1. Carefully cut off the old foam grip with a box cutter or knife making sure you don't chip the paint on the support arm of the CoverMate.
2. Unscrew the support arm from the pivot arm.
3. Liberally spray the support arm with a non-soapy solution like Simple Green or 409. You can also dunk the foam grip in this solution prior to putting it on the support arm.
4. Pull the new foam grip on to the support arm until you have it in the correct position.
5. Reattach the support arm to the pivot arm.